

Buck-Boost Connection Diagram

Use the following information for single-phase autotransformer connections.

NOTE: Inputs and outputs may be reversed; KVA capacity remains constant. All applications are suitable for 60 Hz. only.

IMPORTANT: Refer to the N.E.C. (National Electrical Code) Article 450-4 for overcurrent protection of an autotransformer.

